

18. PARTS LIST URS2000 SERIES

ITEM	NAME AND	PART NO.	ITEM	NAME AND	PART NO.
1	SAFETY COVER ASSY	960-3310	43	HEATER TERMINAL COVER	
2	PULL HANDLE, DOOR & LID	120-318	44	HEATER THERMOSTAT	
3	STAY, SAFETY COVER	960-3410	45	WIRE, HEATER - THERMOSTAT	
4	FRICTION PLATE, LID	770-3370	46	CONDENSER THERMOSTAT	
5	SIDE COVER ASSY STAY	770-3730	47	SHORT NIPPLE, 1/2"NPT, 2"L	960-4261
6	SWITCH PANEL, URS900/2000		48	ELBOW, 90 DEG, 1/2"NPTFx2	960-4262
7	TIMER KNOB, BLACK	100-261F	49	LONG NIPPLE, 1/2"NPTMx2, 8"L	960-4265
8	TIMER ASSEMBLY, 5 MINUTES	115-200/5	50	HEX NIPPLE, 1/2"NPT-3/4"	770-4281S
9	RIGHT BACK PANEL, URS2000	960-3751	51	UNION ASSY, 1/2"NPTx2	700-4283
9b	LEFT BACK PANEL, URS2000	960-3753	52	STREET ELBOW, 1/2", 90	770-4282
10	LID GASKET, NEOPRENE,	965-2150N	53	POWER CORD, URS500-URS2000	
	LID GASKET, EP, BLACK, 70D	965-2150E	54	MOTOR HOUSING COVER	
	LID GASKET, VITON, BLACK, 70D	965-2150V	55	FAN ASSY, 10", 5 FIN, CW	770-4220
11	TANK LID ASSY, SS, URS2000	960-2000S	56	SNAP RING, MOTOR COVER	600-4131
12	HINGE PIN BOLT, 3/8"-16	99-436HH	57	FAN MOTOR ASSEMBLY	960-4210
13	HEX LOCK NUT, HINGE PIN, 3/8"	99-543DH	58	O-RING, MOTOR SUPPORT	600-4137
14	PUSH LEVER, SAFETY COVER,	960-3371	59	CONNECTOR, POWER CORD	770-4284
15	PUSH BUTTON, SAFETY COVER	960-3374	60	SEALING FITTING, 1/2"NPT	
16	LID CLAMP ASSY	960-2240L	61	SNAP RING, MOTOR SUPPORT	600-4133
17	FRONT CLAMP CATCH ASSY, SS	960-2260A	62	MOTOR HOUSING ASSY, URS2000	
18	LID HOLDER BAR ASSY,	965-2230A	63	CONNECTOR, COMPUTER CORD	770-4283
19	LID CLOSER SPRING	960-	64	POWER BOARD ASSY, 220/240V	
20	U-BRACKET ASSY, LOWER	960-2251	65	FRONT COVER ASSY, MOTOR	900-4320
21	TANK & HEATER ASSY, SS,	960-1100SAF	66	TRANSF. OUTLET ELBOW TUBE,	960-8365
22	LOCK PLATE, SAFETY COVER	960-1911		TRANSF. OUTLET ELBOW TUBE,	960-8365S
23	RETAINER FRAME, SS, URS2000	960-9110	70	TANK FILLER HOSE ASSEMBLY	960-8240
24	BOTTOM INSULATOR PAD	960-1230	71	GROUND WIRE ASSEMBLY	
25	SIDE INSULATOR PAD	960-1210	72	DIAPHRAGM PUMP ASSY, TANK	UDP4TA
27	TANK FILLER OUTLET ELBOW,	Z105-B	73	DIAPHRAGM PUMP ASSY,	UDP4TA
	TANK FILLER OUTLET ELBOW,	Z105-BS	74	ADJUSTABLE FOOT	110-531L
28	REDUCER NIPPLE,	Z123-DB	75	TANK FILLER SUCTION PIPE	960-8250
	REDUCER NIPPLE,	Z123-DBS		TANK FILLER SUCTION PIPE	960-8250S
29	HEX NUT, BRASS, 1/2"NPT	Z111-D	76	CABINET DOOR, SS18G, URS2000	960-3210
30	TANK FILLER VALVE ASSY,	750-3310	77	POSITIVE DOOR LOCK ASSY	
	TANK FILLER VALVE ASSY, SS	750-3310S	78	AIR INLET ASSY w/PRESS.	120-020PR
31	ELBOW FITTING, 90°, BRASS	770-8140	79	TRANSFER SUCTION PIPE ASSY,	960-8350
	ELBOW FITTING, 90, SS	770-8140S		TRANSFER SUCTION PIPE ASSY,	960-8350S
32	VAPOR OUTLET ASSY "L",	770-1151L	80	GROUND WIRE w/CLIP	960-8310
	VAPOR OUTLET ASSY "L", SS	770-1151LS	81	UNION COUPLER, MALE FITTING,	600-8311
33	HEX REDUCER, 3/8"NPT-1/4"NPT	Z123-CB		UNION COUPLER, MALE FITTING,	600-8311S
34	COMPUTER BOARD		82	TANK FILLER SUCTION HOSE	960-
35	TUBE CONNECTOR, 1/4"NPTM	Z668-8B	83	SOLVENT OUTLET TUBE	960-8121
	TUBE CONNECTOR, 1/4"NPTM,	Z668-8BS	84	CARRYING HANDLE	600-3112
36	CHECK VALVE "T" ASSY, BRASS	960-8150	86	TRANSFER HOSE ASSEMBLY, 4'	960-8360
	CHECK VALVE "T" ASSY, SS	960-8150S	87	SOLVENT HOSE	
37	VAPOR OUTLET TUBE	960-1155	88	FAN SHROUD PANEL	960-
	VAPOR OUTLET TUBE, SS	960-1155S	89	SOLVENT OUTLET ELBOW PIPE	960-8131
38	CONDENSER ASSY, COPPER		90	SERVICE ACCESS DOOR ASSY	960-
	CONDENSER ASSY, SS TUBES		91	WASTE HOLDING TANK ASSY	
40	HOSE CLAMP #5, SS	100-261S	92	DRAIN NIPPLE	
41	3-WAY CONNECTOR ASSY,	960-8140	93	MANUAL DRAIN VALVE ASSY	
41	3-WAY CONNECTOR ASSY, SS	960-8140S	94	DRAIN VALVE HANDLE	
42	SOLVENT HOSE, PE, T-OUTLET	960-8123	95	DRAIN VALVE SHAFT	

19. PARTS ILLUSTRATION

URS2000 SERIES

